

Supplement for Zero Turn Mowers

Installing the Deck Adapter Kit, (DAK), or Chute Adapter Kit, to your Zero Turn Mower, (ZTM), will require a support bracket for the end of the Discharge Tube.

The ZTM does not have a fender covering the rear wheel. The end of the discharge tube is normally secured to the rear fender. Therefore a bracket will be needed to support the end of the discharge tube. The bracket can be as simple as a broomstick, zip tied or taped to the rear frame. The bracket must be long enough to extend past the rear tire and support the discharge tube, but should not stick out much further than needed. The bracket can support the tube from below or above and is secured to the bracket using one of the rope ratchets.



Tire sticks out past the fender/gas tank.



Fancy bracket installed to support discharge tube.